Lenovo Service Center - Lenovo Service Centers Contacts

Generated: 5 November, 2025, 07:00

_apto	p won't	come	out	of sle	ері	mode.	HEI	LP!!!!
osted by	lenovoadm	in - 06 Jan	2017	12:38	•			

Try this and see if it helps.

- 1. Go to and click the "Power Icon" and then click "More Power Options".
- 2. Under the plan that is currently selected (Balanced, Power Saver....) click "Change Plan Settings".
- 3. Now click " Change Advanced Power Settings ".
- 4. On the next screen you may have to click at top of screen on " Change settings that are currently unavailable ".
- 5. Open the "Sleep Setting" and find "Hybrid Sleep"
- 6. Change/set it to allow.
- 7. Click "OK".
- 8. Finally shut down and power up the computer.
