## **Lenovo Service Center - Lenovo Service Centers Contacts** Generated: 4 November, 2025, 23:43

Lenovo Ideapad Iaptop doesn't start Posted by Ienovoadmin - 06 Jan 2017 06:38
Hi,
Γry ths 1
1. remove battery and unplug from wall
2. press start button and hold down for 60 seconds
3. install battery and power cord
4. start laptop normally