

## Lenovo y50 keeps turning on and off

Posted by lenovoadmin - 06 Jan 2017 06:43

---

Hi, remove the RAM and put them back.

=====