## **Lenovo Service Center - Lenovo Service Centers Contacts**

Generated: 2 July, 2025, 14:21

	, .			•	
$\Delta D \Delta V \Delta V$	COLICE	Lantan	$n \cap t$	powering	IID
		1 4()(()()	11()1	1000000	1111
	001100	LUDIUD	1101		$\omega$

Posted by lenovoadmin - 06 Jan 2017 06:49

Removed Battery and switched on AC power - still lifeless!

Replaced battery, disconnected AC chord, pressed POWER button for >45secs, put back AC connection, tried powering up - still lifeless!

Removed battery, removed AC line, pressed POWER for >45 secs, connected AC chord back only( not battery ), repeated procedure 3 times - still lifeless!

Put the battery again and switched on the main power! the orange indicator for AC power turned on.

I pressed the POWER and it booted right up - However, the battery was completely out of order.

But I could at least work off AC power!

\_\_\_\_\_\_