

My Lenovo laptop G50-45 Boots But No Display

Posted by lenovoadmin - 06 Jan 2017 10:51

You can also start by flushing out all static, remove battery and AC adaptor and hold down power button for about 15 seconds.

Try re-seating the HDD module & check if issue still persist or not.

=====